HI 729

Fluoride Low Range





Dear Customer.

Thank you for choosing a Hanna Instruments Product.

Please read this instruction manual carefully before using the instrument. If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com.

Preliminary examination:

Please examine this product carefully. Make sure that the instrument is not damaged. If any damage occurred during shipment, please notify your Dealer. Each HI 729 meter is supplied complete with:

- Two Sample Cuvettes and Caps
- 1 bottle (30 mL) of HI 729S Fluoride LR Reagent
- 1 mL syringe with tip
- 1 x 1.5V AAA Battery
- Instruction Manual



For more details about spare parts and accessories see "Accessories".

Technical specifications:
0.00 to 2.00 ppm
0.01 ppm
± 0.10 ppm ± 5 % of reading @ 25 °C / 77 °F
± 0.01 ppm
Light Emitting Diode @ 575 nm
Silicon Photocell
Adaptation of the <i>Standard Methods for the Examination</i> of Water and Wastewater, 18 th edition, SPADNS method.
0 to 50 °C (32 to 122 °F); max 95% RH non-condensing
1 x 1.5V AAA
After 10 minutes of non-use
81.5 x 61 x 37.5 mm (3.2 x 2.4 x 1.5")
64 g (2.25 oz.)

Functional description:




- 1 Dust cover
- 2. Cuvette with cap.
- 3 Cuvette holder
- 4. Liquid Crystal Display.
- Button

Errors and warnings:



Light High: There is too much light to perform a measurement. Please check the preparation of the zero cuvette.





Inverted cuvettes: The sample and the zero cuvette are inverted.



Under range: A blinking "0.00" indicates that the sample absorbs more light than the zero reference. Check the procedure and make sure that the sample and zero cuvette are not inverted.



Over Range: A flashing value of the maximum concentration indicates the reading is over range. Dilute the sample and re-run the test.



 $\textbf{Battery low:} \ \ \text{The battery must be replaced soon.}$



hAŁ

Dead battery: This indicates that the battery is dead and must be replaced. Once this indication is displayed, normal operation of the instrument will be interrupted. Change the battery and restart the meter.